

October 14, 2008



Thin-film barrier on foil for organic LED lamps

Ferdie van Assche, Harmen Rooms,
Jasper Michels, Edward Young, Ton van Mol
Holst Centre

Gerard Rietjens, Peter van de Weijer, Piet Bouten
Philips Research Laboratories

Contents

- **Research topics at the Holst Centre**
- **OLEDs on foil for lighting, ultra barrier specifications**
- **Ca-mirror test**
- **Crack channeling strain of a-SiN_x:H**
- **Repetitive bending test on complete barriers on foil**
- **Conclusions**

Earth at Night

More information available at:

<http://antwrp.gsfc.nasa.gov/apod/ap020811.html>

Astronomy Picture of the Day

2002 August 11

<http://antwrp.gsfc.nasa.gov/apod/astropix.html>

Research topics at the Holst Centre


Strategic programs:
windows on application areas, guiding choices in the technology programs

Technology programs:
Development of key technologies

	Printed Organic Lighting & Signage	Smart Bandage	Smart Blister
Large Area Printing	■ ■	■ □	■ □
Electrodes and Barriers	■ ■	■ □	■ □
Foils Integration	■ □	■ □	■ □
Printed Structures on Foil	■ □	■ □	■ □
Organic Circuitry	□ □	■ ■	■ ■
Lithography on Foil	□ □	■ ■	■ ■




OLEDs for lighting and signage applications



OLEDs need encapsulation

- OLEDs' low work function cathodes oxidize rapidly




- Black spots form due to water diffusion through pinholes in Al cathode
- Black spots grow linearly in time, shelf effect

Requirements for a barrier

- **Almost hermetic**
 - maximum water vapor transmission rate estimated at $\sim 10^{-6}\text{g/m}^2\text{day}$
- **No black spots**
 - Low pinhole density, pinhole coverage
- **Low cost**
 - High deposition rates
- **Feasibility for R2R**
 - *Barriers should be bendable*


Approach: SiN–organic planarization layer–SiN



- **Plasma deposited amorphous hydrogenated silicon nitride (a-SiN_x:H)**
 - RF 13.56 MHz driven parallel plate source
 - Static substrate
 - SiH₄/NH₃/N₂ gas mixture, tens-hundreds of sccm
 - Pressure 0.1-1 mbar, roots pump
 - Substrate temperature 100-130°C
 - Typical deposition rate: 0.5 nm/s
 - *Intended for proof of principle of barrier configuration, plasma source not feasible for low cost production line*
- **Organic planarization layer is used to spatially separate defects**

Ca-mirror test of barriers


- **Degradation of Ca layer: Ca (reflective) + -O → CaO (transparent)**
 - Measurement of WVTR down to 10^{-6} g/m²day
 - Visualisation of defects
- **Initial tests on unbended barriers**



Test configuration


Ca-mirror test of barriers

67 days, 20°C/50%rH



No decay, test ongoing



25 days, 60°C/90%rH



WVTR = $5 \cdot 10^{-5}$ g/m²day, local failure after three weeks for most samples

- No measurable decay after 2 months at ambient conditions
- At 60°C/90%: WVTR = $5 \cdot 10^{-5}$ g/m²day, defects appear only after 3 weeks for most samples
- Estimated WVTR at ambient conditions < 10^{-6} g/m²day

Critical strain measurement method





$$\epsilon_{\max} = \frac{1.198h}{L}$$

- 2-point bending test on Carbon coated a-SiNx:H
 - Maximum tensile strain on outer edge
 - Electrical resistance monitored to detect crack formation Ca (reflective) + -O → CaO (transparent)



Bouten, Leterrier et al, Flexible flat panel displays. 2005, John Wiley & Sons, p.528

Bare PEN foil



- Resistance increase at $\epsilon = 1.2\%$

Critical strain of a-SiN_x:H films




- **Critical strain of a-SiN_x:H on PEN foil: $\epsilon_c = 0.6-0.8\%$**
 - For a 125 μ m thick foil, this corresponds to radius of 11 mm
- **Identical films: spread in ϵ_c may be caused by defect distribution**

Testing of complete barrier: bending test setup





- Minimum bending radius of 14 mm
- 5-100 bends
- Compressive and tensile strain on barrier
- Ca test performed before and after bending




Bending test of (not fully optimized) barrier

- Bending radii: ~10 cm—1.4 cm, 5—100 times
- WVTR before bending $7 \cdot 10^{-5}$ - $1 \cdot 10^{-4}$ g/m²day (1 week at 20°C/50%rH)
- WVTR after bending still in same range, no white spots



Critical bending radius of barrier stack

Comparison WVTR before and after bending





- More close look reveals critical bending radius of ~20 mm
- Amount of bending cycles not important
- Factor of 2 increase suggests failure of top a-SiN_x:H

Ratio of unbended samples not equal to 1. This may be due non-linear Ca transparency vs WVTR in initial oxidation stage

Bending test on optimized barrier, 60°C/90%

- More aggressive bending radius/larger amount of cycles: 1.4 cm, 100–400 times
- At 60°/90% WVTR = $5 \cdot 10^{-5}$ g/m²day
- After (too aggressive) bending immediate local decay



- To be repeated at more gentle bending angles

Conclusions

- Barriers on PEN foil have been produced with a WVTR of $5 \cdot 10^{-5}$ g/m²day at 60°C/90%rH conditions
- At ambient conditions no decay visible after 2 months, WVTR estimated $< 10^{-6}$ g/m²day
- Barrier bendable down to a minimum radius of 20 mm, hence suitable for R2R
- A crack channeling strain of 0.6-0.8% has been measured for 300 nm thick a-SiN_x:H on PEN foil

Near future

- Bending testing of encapsulated OLEDs
- Scaling up to pilot sheet-to-sheet, then R2R line for barrier and cathode
 - Implementation of microwave plasma source

Acknowledgements

Holst TP2 team

- Joris de Riet
- Jan Manders


MiPlaza team

- Jan Janssen
- Ibrahima Faye
- Paul Aerts
- Tom Bernardts
- Martin Hack
- Marc Kuilder
- Martine Meulendijk
- Pieter Klaassen

Industrial Residents

- Erik Dekempeneer (Bekaert)
- Roger Degrijse (Bekaert)
- Rudi van Paemel (U Gent)
- Herbert Lifka (Philips)
- Cristina Tanase (Philips)
- Dimiter Kotzev (Huntsman)
- Richard Frantz (Huntsman)
- Emilie Galand (Huntsman)
- Mathias Graeber (Huntsman)

Financially supported by the Dutch Ministry of Economic Affairs, Philips, Bekaert, OTB Display and Huntsman



Questions or Remarks?

Thank you for your attention!

Ferdie van Assche, MSc

T: + 31 6 12 642 246

E: ferdie.vanassche@tno.nl